


***Finite Element Analysis to Investigate Electromagnetic
Flowmeters of Diverse Cross sectional Shapes***

Subhashish Dasgupta
Principal Scientist,
ABB Corporate Research, Bangalore

Electromagnetic Flowmeter: Working Principal

Faraday's Law in action




EM Flowmeter


- Ionic liquid flows across magnetic field
- EMF induced in accordance with Faraday's Law of electromagnetic induction
- Induced EMF is proportional to velocity

*Scientific model required to improve understanding of complexities
- design improvement*

Finite Element Model of Flowmeter



Domain Discretization



Mesh

- Tetrahedral meshing scheme
- Mesh resolved in zones of complicity: Boundary layer
- Mesh independence study performed

Finite Element Model of Flowmeter

Governing Equations

Fluid Flow

Fluid flow module

Mass Conservation

$$\nabla \cdot u = 0$$

Momentum Conservation

$$\rho u \nabla u = -\nabla p + \mu \nabla^2 u + F$$

u – Velocity

p – Pressure

μ – Viscosity

Electromagnetics

Magnetic and Electric Fields

Ampere's law

$$\nabla \times \mu_0^{-1} \mu_r^{-1} B = J$$

Current Conservation

$$\nabla \cdot J = 0$$

Lorentz Term (Faraday's Law)

$$J_i = \sigma E + \sigma u \times B \quad \Rightarrow \quad E = -\nabla \phi$$


B – Magnetic flux density

J – Current

E – Induced electric field

- **Interaction of flow and magnetics**
- **Integration provides induced potential**

Model Structure




- Steady state simulation
- Segregated Direct Solvers for fluid flow
- Iterative solver for electromagnetics
- Solvers interaction between velocity and magnetic flux


Influence of Pipe Cross Sectional Shape

- Circular, square and rectangular cross sectional shapes chosen
- Constant area and width
- Varying height


Coil



Coil



Coil







Coil


Coil

Coil



Magnetic Flux Density



Influence of Pipe Cross Sectional Shape





Fluid Flow





Indicates developing flow

Induced Electric Potential



Influence of Pipe Cross Sectional Shape






- Triangular shaped flowmeter yields best sensitivity
- Pressure drop 45% higher in triangular shaped flowmeter
- **Conclusion: Circular shaped flowmeter yields overall best performance**

Model Validation

1. Magnetic Flux Calculation Method

Saddle shaped coils




Model vs. Test data

Magnetic flux density measured along x, y directions

- *Within 95% agreement*
- *Validates magnetic flux modeling method*

2. EM Flowmeter Sensitivity Calculation



Within 95% agreement

- **Model validation:** 2 step process
- Magnetic flux modeling method validated using literature data (test)
- Flowmeter sensitivity validated against in-house test data
- *Overall model predicts with acceptable accuracy: ~ 95%*
- Useful predictive tool for industry